

Where to find UBS-Mini port in PVC20-24



Behind the front cover is a USB mini connector

Remove the front cover with a small screwdriver by gently pushing on the tabs.